

ABUTMENT SKEW CORRECTION FACTOR (SCF) = 1.064

(Left Skew as shown;right skew opp. hand)

NOTE: Trim A16 & A17 bars if necessary
Trim A3 bars as necessary



— Place 4" weep hole drains at 8'-0" centers at such elevation as to afford best drainage of backfill, in accordance with the Standard Specifications.

