






TWIST UNSHIELDED LOOP WIRES (IMSA 51-7) WITH 3 TO 5 TURNS PER FOOT FROM THE START OF THE HOMERUN TO THE JUNCTION BOX, CABINET, OR POLE. SLOT CAN BE WIDEN TO 1/2" TO 5/8" TO HELP WITH THE INSTALLATION OF THE TWISTED WIRE.


SECTION B-B (TWIST NOTE)  
-FOR CANCELING OUT CROSSTALK



6'X6' LOOP



PREFORMED LOOP DIAGRAM




6'x6' PREFORMED LOOP

CONSTRUCTION DETAILS FOR LOOP SAW SLOT AND FILL BID ITEM :


THE FOLLOWING IS A TYPICAL STEP BY STEP PROCEDURE FOR THE INSTALLATION OF A LOOP.

- \* CAREFULLY MARK THE SLOT TO BE CUT, PERPENDICULAR TO THE FLOW OF TRAFFIC AND CENTERED IN THE LANE.
- \* MAKE EACH SAW-CUT 3/8 INCH WIDE AND AT A DEPTH SUCH THAT THE TOP OF THE BACKER ROD IS A MINIMUM OF 4 INCHES BELOW THE SURFACE OF ASPHALT PAVEMENT.
- \* DRILL A 1 1/2 INCH CORE HOLE AT EACH CORNER AND USE A CHISEL TO SMOOTHE CORNERS TO PREVENT SHARP BENDS IN THE WIRE.
- \* CLEAN ALL FOREIGN AND LOOSE MATTER OUT OF THE SLOTS, DRILLED CORES, AND WITHIN 1 FOOT ON ALL SIDES OF THE SLOTS USING A HIGH PRESSURE WASHER.
- \* COMPLETELY DRY THE SLOTS, DRILLED CORES, AND WITHIN 1 FOOT ON ALL SIDES OF THE SLOTS.
- \* MEASURE 9-12 INCHES FROM THE EDGE OF THE PAVED SURFACE (SHOULDER BREAK OR FACE OF CURB) AND DRILL A 1 1/2 INCH HOLE ON A 45 DEGREE ANGLE TO THE CONDUIT ADJACENT TO THE ROADWAY.
- \* CLOSELY INSPECT ALL CUTS, CORES, AND SLOTS FOR JAGGED EDGES OR PROTRUSIONS PRIOR TO THE PLACEMENT OF THE WIRE. ALL JAGGED EDGES AND PROTRUSIONS SHALL BE GROUND OR RE-CUT AND CLEANED AGAIN.
- \* INSTALL 1" RIGID STEEL CONDUIT IN 45 DEGREE DRILLED SLOT. CONNECT CONDUIT TO 1" RIGID STEEL CONDUIT ADJACENT TO THE ROADWAY WITH RIGID STEEL ELBOW. PLACE THE LOOP WIRE SPLICE-FREE FROM THE TERMINATION POINT . **SEE SECTION B-B NOTE.**
- \* **PUSH THE WIRE INTO THE SAW SLOT WITH A BLUNT OBJECT SUCH AS A WOODEN STICK. MAKE SURE THAT THE LOOP WIRE IS PUSHED FULLY TO THE BOTTOM OF THE SAW SLOT. SCREWDRIVERS SHALL NOT BE USED.**
- \* INSTALL DUCT SEALANT TO A MINIMUM OF 1 INCH DEEP INTO THE CORED 1 1/2 INCH HOLE.
- \* APPLY LOOP SEALANT FROM THE BOTTOM UP AND FULLY ENCAPSULATE THE LOOP WIRES IN THE SAW SLOT. THE WIRE SHOULD NOT BE ABLE TO MOVE WHEN THE SEALANT HAS SET.
- \* COVER THE ENCAPSULATED LOOP WIRE WITH A CONTINUOUS LAYER OF BACKER ROD ALONG THE ENTIRE LOOP AND HOME RUN SAW SLOTS SUCH THAT NO VOIDS ARE PRESENT BETWEEN THE LOOP SEALANT AND BACKER ROD.
- \* FINISH FILLING THE SAW CUT WITH NON-SHRINKABLE GROUT PER MANUFACTURER'S INSTRUCTIONS. ALLEVIATE ALL AIR POCKETS AND REFILL LOW SPACES. THERE SHALL BE NO CONCAVE PORTION TO THE GROUT IN THE SAW SLOT. ANY EXCESS GROUT SHALL BE CLEANED FROM THE ROADWAY TO ALLEVIATE TRACKING.
- \* CLEAN UP THE SITE AND DISPOSE OF ALL WASTE OFF THE PROJECT.
- \* ENSURE THAT THE GROUT HAS COMPLETELY CURED PRIOR TO SUBJECTING THE LOOP TO TRAFFIC. CURING TIME VARIES WITH TEMPERATURE AND HUMIDITY.

PREFORMED LOOP LEAD-IN SHALL BE TWISTED WITH THREE TO FIVE TURNS PER FOOT UNTIL TERMINATED AT FIELD CONNECTIONS IN THE CABINET OR CONNECTED TO SHIELDED CABLE.



PREFORMED LOOP DIAGRAM



6'x30' QUADRAPOLE PREFORMED LOOP

LOOP DETAILS


FILE NAME: C:\USERS\JESSICA.GOODWIN\DESKTOP\04-LOOPS (LP).DGN

USER: Jessica.Goodwin  
DATE PLOTTED: December 2, 2021

E-SHEET NAME:

OpenRoads Designer v23.00.01.11

7/1/2025



6'X30' QUADRAPOLE LOOP